

# HPGP™ 101-C

Ultra High Purity Gas Particle Counter and PDS-E

*Provides reliable in-line contamination monitoring for process gases at line pressure*

*Without measurement there is no control*

High-technology manufacturing processes often require high-purity gases. The HPGP 101-C provides reliable in-line contamination monitoring for process gases at line pressure.

The HPGP is compatible with most non-toxic gases and can be used in many reactive gas monitoring applications.

The PDS-E (Particle Data System - Ethernet) instrument collects and reports data captured by the HPGP 101-C probe.



## BENEFITS

### Reduced Cost

- Speed qualification of process gas distribution systems
- Detect particles in gases before they impact yield
- Compatible with oxygen, hydrogen, and most non-toxic gases

### Improved Process Control

- Verify gas quality
- Detect process upsets
- Quantify impact of system changes
- Accurate particle sizing
- Facility Net data management software for comprehensive data storage, management, reports, and alarms

### Reliable

- Passive cavity design requires infrequent maintenance
- Inert gas purge ensures safety
- Leakage of sample gas to vessel discontinues power to electronics

## FEATURES

- 0.1  $\mu\text{m}$  sensitivity at 0.1 SCFM
- 8 particle channels
- Line pressures from 40 to 150 psig
- Passive laser cavity
- Parallel processing array detector system
- Safety containment vessel
- Oxygen and hydrogen compatibility
- CE and RoHS 2 compliant

## APPLICATIONS

- Qualification of gas distribution systems
- Process gas monitoring
- Reactive gas monitoring

Particle Counter	CDA	N <sub>2</sub>	Ar	CO <sub>2</sub>	O <sub>2</sub> /He/ Ne/ H <sub>2</sub>
Airnet	Y	Y	N	N	N
Lasair III 110	Y	Y	N	N	N
Lasair III 310	Y	Y	Y	N	N
IsoAir 310P	Y	Y	Y	N	N
IsoAir Pro-E/Plus	Y	Y	Y	Y	N
Lasair Pro	Y	Y	Y	Y	N
HPGP 101-C	Y	Y	Y	Y	Y

# HPGP™ 101-C

Ultra High Purity Gas Particle Counter and PDS-E

Specifications

## HPGP 101-C

Size channels	8 channels with thresholds at: 0.1, 0.2, 0.3, 0.5, 1.0, 2.0, 3.0, 5.0 µm
Sample rate	0.1 SCFM (2.8 LPM) (=total volumetric flow rate)
Counting efficiency*	> 50% at 0.14 µm
Zero count level	< 2/ft <sup>3</sup> or < 0.2/min
Maximum concentration**	3,000/ft <sup>3</sup>
Laser type	HeNe
Calibration	Traceable to the US National Institute of Standards and Technology (NIST).
Power	100, 115, 220 – 230, or 230 – 240 V, 50 – 60 Hz, 0.5 A
Environment	Temperature: 32 – 113 °F (0 – 45 °C). Humidity: non-condensing. Maximum altitude: 9,842 ft (3,000 m).
Dimensions (l, w, h)	26 x 8 x 9 in (66 x 20 x 22 cm)
Weight	45 lb (20.4 kg)
Compliance	CE, RoHS 2

## PDS-E (Data Interface)

Number of sensors	Supports 1 HPGP unit per PDS-E
Sampling interval	1 sec to 8 hr
Computer interface	RS-232, bi-directional; Ethernet (via PMS protocol, Modbus, or OPC)
Power	100 – 240 VAC, 50 – 60 Hz, 0.63 A
Environment	Temperature: 32 – 113 °F (0 – 45 °C), Humidity: non-condensing, Maximum altitude: 9,842 ft (3,000 m)
Dimensions (l, w, h)	7 x 8.5 x 12.5 in (18 x 22 x 32 cm)
Weight	11.5 lb (5.2 kg)

\* Allow ± 5% for variations in sample flow.

\*\* Greater than 90% accuracy (less than 10% coincidence loss) at maximum recommendation ambient concentration.

Patents apply: United States – 4,798,465, 4,893,928, and 4,594,715. Japan – 2,786,187, and 2,554,614. Germany – 3,712,665C2, 3,930,642, and 3,485,749.4. Canada – 1,228,148. UK – EP142815.


### HEADQUARTERS

5475 Airport Blvd  
Boulder, Colorado 80301 USA  
T: +1 303 443 7100

Instrument Service & Support  
T: +1 800 557 6363

Customer Response Center  
T: +1 877 475 3317  
E: info@pmeasuring.com

www.pmeasuring.com  
info@pmeasuring.com



### GLOBAL OFFICES

AUSTRIA  
T: +43 512 390 500  
E: pmsaustria@pmeasuring.com

BENELUX  
T: +32 10 23 71 56  
E: pmsbelgium@pmeasuring.com

BRAZIL  
T: +55 11 5188 8227  
E: pmsbrazil@pmeasuring.com

CHINA  
T: +86 21 6113 3600  
E: pmschina@pmeasuring.com

FRANCE  
T: 33(0)1 60 10 32 96  
E: pmsfrance@pmeasuring.com

GERMANY  
T: +49 6151 6671 632  
E: pmsgermany@pmeasuring.com

ITALY  
T: +39 06 9053 0130  
E: pmssrl@pmeasuring.com

JAPAN  
T: +81 44 589 3498  
E: pmsjapan@pmeasuring.com

KOREA  
T: +82 31 286 5790  
E: pmskorea@pmeasuring.com

MEXICO  
T: +52 55 2271 5106  
E: pmsmexico@pmeasuring.com

NORDIC  
T: +45 707 028 55  
E: pmsnordic@pmeasuring.com

PUERTO RICO  
T: +1 787 718 9096  
E: pmspuertorico@pmeasuring.com

SINGAPORE  
T: +65 6496 0330  
E: pmssingapore@pmeasuring.com

SWITZERLAND  
T: +41 71 987 01 01  
E: pmsswitzerland@pmeasuring.com

TAIWAN  
T: 886-3-5525300 Ext: 301  
E: pmstaiwan@pmeasuring.com



All trademarks are the property of their respective owners. Particle Measuring Systems, Inc. reserves the right to change specifications without notice. © 2022 Particle Measuring Systems, Inc. All rights reserved. 09212022