

Without measurement there is no control®

Airnet® II_s

Stainless Steel 2-Channel Particle Sensor



Unparalleled performance in a compact, 316L stainless steel enclosure, engineered to meet ISO 21501-4 and ISO 14644-1:2015.

The Airnet® II_s particle sensor makes it easy and cost-effective to monitor your cleanroom. This particle sensor offers a small footprint, unparalleled performance, and data transmission capabilities while meeting the specification of ISO 21501-4 and ISO 14644-1:2015, all enclosed in a 316L Stainless Steel case.

Simple installation with one single cable, using Power Over Ethernet (PoE) Technology. Communication capabilities include Ethernet to interface with and PharmaceuticalNet™, FacilityNet™, or FacilityPro® software, Modbus TCP/IP communications.

Data integrity is maintained through the use of a data queue feature that continues to gather data even if network communication is lost.

To ensure proper flow conditions and vacuum system operation, these units incorporate a Dynamic Flow Sensing system that will alarm with a 15% change in flow conditions.

For applications where decontamination using Vaporized Hydrogen Peroxide (VHP) is required, an optional VHP-compatible unit is available for a simple installation without complex valving (Airnet 510XR).

BENEFITS

- Proven technology provides reliable and accurate data
- Allows for immediate reaction to particle contamination events
- A low-cost solution for multipoint monitoring
- Interfaces with PharmaceuticalNet™, FacilityNet™, and FacilityPro® software for comprehensive management of cleanroom conditions
- A small footprint and wall mounting bracket make it easy to install in cleanrooms and mini-environments.
- A laser diode (LD) drastically reduces the need for maintenance and extends product lifecycle.
- Automatic laser shutdown reduces laser failures.
- Data queue maintains data integrity when communication is lost.
- Optional XR coating protects sensors against corrosive or oxidizing vapors in VHP sterilization processes.

FEATURES

- 2 channels
- 0.5 and 5.0 µm size range, suitable for Pharmaceutical application
- 1.0 CFM flow rate
- Chemical-resistant 316L Stainless Steel enclosure
- Low sample point cost
- Small enough for use in remote locations
- ISO 14644-1:2015 Compliant
- ISO 21501-4 Compliant

APPLICATIONS

- Cleanroom monitoring
- Dedicated monitoring of critical locations
- Trend analysis
- Statistical process control
- Multi-location monitoring
- Isolator monitoring

Airnet® II_S Stainless Steel 2 Channel Particle Sensor

MODEL	510S and 510S XR
Size Range	0.5, 5.0 µm
Flow Rate	1.0 CFM (28.3 LPM)
Counting Efficiency	50% ± 20% for most-sensitive channel. Meets ISO 21501-4 100% ± 10% at 1.5 to 2.0 times channel one size. Meets ISO 21501-4.
Zero Count	≤ 7.07 counts/m ³
Maximum Concentration ¹	957,824/ft ³
Laser Source	Diode
Laser Classification	Class 1 per EN60825 (Internally, a Class IIIB laser is used, per EN60825)
Exterior Surface	316L Stainless Steel
Dimensions (H x W x L)	3.5 x 7.1 x 4.0 in (8.9 x 18.0 x 10.2 cm) without ISP and bracket
Weight	2.4 lb (1.08 kg)
Vacuum Connection	8 mm OD tubing
Flow System	External vacuum required; automatic laser shutoff and alarm on 15% flow variation
Vacuum Source	> 15 in Hg (> 410 mBar) below atm pressure
Power	Power over Ethernet 48 VDC via a PoE router
Communication Connectors	Ethernet (Particle Measuring Systems proprietary protocol and Modbus TCP) RS-232 (configuration and diagnostic tool only, no data)
Status Indicators	Programmable status (two-color LED), Activity (one-color LED)
Calibration	Calibration materials used are traceable to the National Institute of Standards and Technology (NIST) and meet ISO 21501-4 requirements. Optional ISO 17025 calibration available.
Ingress Protection	IP65
Environment	Temperature: 4 – 35 °C (32 – 95 °F) Humidity: 5 – 95% non-condensing relative
Complies with	EU RoHS, ISO 21501-4, ISO 14644-1:2015



Airnet II with wall mounting bracket



316L Stainless Steel Wall Mounting Bracket, included

¹10% coincidence loss at maximum concentration.

NEED MORE INFORMATION? Scan the QR code to connect with our team for guidance



HEADQUARTERS

7477 E. Dry Creek Parkway,
Niwot, CO, 80503 USA
T: +1 303 443 7100

Instrument Service & Support
T: +1 303-443-7100 ext.447

Service and Calibration
E: workorders@pmeasuring.com

Technical Support
E: techsupport@pmeasuring.com

Software or System Support
E: ssupport@pmeasuring.com

Customer Service
and Order Processing
E: customerorders@pmeasuring.com

GLOBAL OFFICES

AUSTRIA
T: +43 171 728 285
E: pmsaustria@pmeasuring.com

BELGIUM/BENELUX
T: +32 10 23 71 56
E: pmsbelgium@pmeasuring.com

BRAZIL
T: +55 11 5188 8227
E: pmsbrazil@pmeasuring.com

CHINA
T: +86 400 081 8020
E: pmschina@pmeasuring.com

FRANCE
T: +33 682 991 798
E: pmsfrance@pmeasuring.com

GERMANY
T: +49 351 8896 3850
E: pmsgermany@pmeasuring.com

IRELAND
T: +353 1 295 7373
E: Info.ie@pmeasuring.com

ITALY
T: +39 06 9053 0130
E: pmsrli@pmeasuring.com

JAPAN
T: +81 44 589 3498
E: pmsjapan@pmeasuring.com

KOREA
T: +82 31 286 5790
E: pmskorea@pmeasuring.com

NORDIC
T: +45 7070 2855
E: pmsnordic@pmeasuring.com

PUERTO RICO
T: +1 786 564 3356
E: pmspuertorico@pmeasuring.com

SINGAPORE
T: +65 6496 0342
E: pmssingapore@pmeasuring.com

SWITZERLAND
T: +41 71 987 01 01
E: pmsswitzerland@pmeasuring.com

TAIWAN
T: 886-3-5525300
E: pmstaiwan@pmeasuring.com

UNITED KINGDOM
T: +44 (0)1733 454 207
E: Info.uk@pmeasuring.com



Airnet® and FacilityPro® are registered trademarks of Particle Measuring Systems, Inc. All other trademarks are the property of their respective owners. Particle Measuring Systems, Inc. reserves the right to change specifications without notice. © 2026 Particle Measuring Systems, Inc. All rights reserved. 05202026